

ANALYTICAL PSEUDO CODE

Import necessary libraries

Define pin connections for relays, servos, motor, load cell, and LCD

Initialize LCD with address 0x27, dimensions 16x2

Initialize Load Cell

Define variables: weight, oldweight, newweight

Setup function:

- Start serial communication at 115200 baud

- Initialize and clear LCD

- Display initial weight on LCD

- Set relay, servo, and motor pins as OUTPUT

- Turn off relays (initialize to LOW)

- Close both valves (initialize valve positions)

- Start load cell with specified pins and calibration scale

- Tare (zero) the scale

Loop function (for 5 iterations) :

- Move spout forward

- Open red servo valve

- Run pump for 3.5 seconds

- Measure and display weight on LCD

- Perform precise measurement adjustment:

 - Check weight incrementally, pump if weight is less than target

 - Stop pumping if target weight is reached

- Put load cell in sleep mode briefly, then wake it

- Update old weight

- Run reverse pump for 4 seconds to remove remaining water

- Close red servo valve

- Move spout back

- Open blue servo valve

- Run pump for 5.5 seconds

- Measure and display weight on LCD

- Perform precise measurement adjustment

- Put load cell in sleep mode briefly, then wake it

Run reverse pump for 4 seconds to remove remaining water
Close blue servo valve

Self-Defined functions:

moveServo(pulseWidth, servoPin):
 Generate PWM signal for the servo using pulseWidth

closeValve(pin):
 Print message indicating which valve is closing
 Sweep servo from 0 to 90 degrees to close the valve

openValve(pin):
 Print message indicating which valve is opening
 Sweep servo from 90 to 0 degrees to open the valve

pump(duration):
 Activate relay for specified duration
 Deactivate relay, wait briefly

reversepump(duration):
 Activate reverse relay for specified duration
 Deactivate relay, wait briefly

precisepump(oldweight,target):
 Loop up to 10 times:
 Measure weight and calculate weight difference from oldweight
 Display weight
 If weight difference is less than target, pump briefly
 If target is reached, stop pumping
 Wait briefly before next check

lcdprint(weight):
 Print weight on serial monitor and LCD display

movespout(forward):
 Set motor direction based on forward or backward
 Rotate motor for a complete revolution

TECHNICAL PSEUDO CODE

```
// Import libraries and define pin connections/constants
```

```
START FUNCTION setup:
```

```
    INITIALIZE Serial at 115200 baud
```

```
    INITIALIZE LCD with 16x2 display
```

```
    DISPLAY "Weight" on LCD
```

```
    SET relayPin, revrelayPin, servobluePin, servoredPin, stepPin, dirPin as OUTPUT
```

```
    TURN OFF relays by setting relayPin, revrelayPin to LOW
```

```
    INITIALIZE both valves to closed by CALLING closeValve(servoredPin) and  
    closeValve(servobluePin)
```

```
    INITIALIZE load cell with pins LOADCELL_DOUT_PIN, LOADCELL_SCK_PIN
```

```
    CALIBRATE scale with set_scale value, tare to zero
```

```
    CALL five_looper() // Start main dispensing sequence
```

```
    DISPLAY "Task Completed" on LCD
```

```
END FUNCTION
```

```
START FUNCTION loop:
```

```
    // Empty main loop, all logic handled in setup
```

```
END FUNCTION
```

```
START FUNCTION five_looper:
```

```
    FOR i FROM 0 TO 4:
```

```
        CALL movespout(true) // Move spout forward
```

```
        CALL openValve(servoredPin) // Open red valve
```

```
        CALL pump(3500) // Run pump for 3.5 seconds
```

```
        SET weight = get_weight() // Measure weight
```

```
        CALL lcdprint(weight) // Display weight
```

```
        CALL precisepump(oldweight, 5.0) // Dispense precisely to reach target weight
```

```
        CALL scale.power_down() // Power down load cell
```

```
        WAIT 1000 milliseconds
```

```
        CALL scale.power_up() // Power up load cell
```

```
    SET oldweight = weight
```

```
    CALL reversepump(4000) // Remove remaining fluid
```

```
    CALL closeValve(servoredPin) // Close red valve
```

```
    CALL movespout(false) // Move spout back
```

```
    CALL openValve(servobluePin) // Open blue valve
```

```
    CALL pump(5500) // Run pump for 5.5 seconds
```

```
    SET weight = get_weight()
```

```

CALL lcdprint(weight)

CALL precisepump(oldweight, 10.0) // Dispense precisely for blue valve
CALL scale.power_down()
WAIT 1000 milliseconds
CALL scale.power_up()

SET oldweight = weight
CALL reversepump(4000)    // Remove remaining fluid
CALL closeValve(servobluePin)
END FOR
END FUNCTION

START FUNCTION moveServo(pulseWidth, servoPin):
  SET servoPin HIGH
  WAIT pulseWidth microseconds
  SET servoPin LOW
  WAIT (20 - (pulseWidth / 1000)) milliseconds // Maintain 20ms period
END FUNCTION

START FUNCTION closeValve(pin):
  IF pin == servoredPin THEN:
    DISPLAY "Closing Red valve"
  ELSE:
    DISPLAY "Closing Blue valve"
  END IF
  FOR angle FROM 0 TO 90:
    SET pulseWidth = map(angle, 0, 180, 500, 2500)
    CALL moveServo(pulseWidth, pin)
    WAIT 15 milliseconds
  END FOR
END FUNCTION

START FUNCTION openValve(pin):
  IF pin == servoredPin THEN:
    DISPLAY "Opening Red valve"
  ELSE:
    DISPLAY "Opening Blue valve"
  END IF
  FOR angle FROM 90 TO 0:
    SET pulseWidth = map(angle, 0, 180, 500, 2500)
    CALL moveServo(pulseWidth, pin)
    WAIT 15 milliseconds
  END FOR
END FUNCTION

START FUNCTION pump(dur):

```

```
    DISPLAY "Pump ON"
    SET relayPin HIGH
    WAIT dur milliseconds
    DISPLAY "Pump OFF"
    SET relayPin LOW
    WAIT 2000 milliseconds
END FUNCTION
```

```
START FUNCTION reversepump(dur):
    DISPLAY "Reverse Pump ON"
    SET revrelayPin HIGH
    WAIT dur milliseconds
    DISPLAY "Reverse Pump OFF"
    SET revrelayPin LOW
    WAIT 2000 milliseconds
END FUNCTION
```

```
START FUNCTION precisepump(oldweight, target):
    FOR i FROM 0 TO 9:
        SET weight = get_weight()
        SET newweight = weight - oldweight
        CALL lcdprint(weight)

        IF newweight < target THEN:
            CALL pump(800)
        ELSE:
            DISPLAY "Target Weight dispensed"
            CALL lcd.clear()
            CALL lcd.setCursor(0, 0)
            lcd.print("Fluid Released: ")
            CALL lcd.setCursor(0, 1)
            lcd.print(newweight / 10.0, 1)
            WAIT 1000 milliseconds
            BREAK
        END IF

        CALL lcdprint(weight)
    END FOR
END FUNCTION
```

```
START FUNCTION lcdprint(weight):
    DISPLAY "Weight: ", weight
    CALL lcd.setCursor(0, 0)
    lcd.print("Weight: ")
    CALL lcd.setCursor(0, 1)
    lcd.print(weight, 1)
END FUNCTION
```

```
START FUNCTION movespout(forw):  
  IF forw THEN:  
    SET dirPin HIGH  
    DISPLAY "Moving Spout Forward"  
  ELSE:  
    SET dirPin LOW  
    DISPLAY "Moving Spout Backward"  
  END IF  
  
  FOR x FROM 0 TO stepsPerRevolution:  
    SET stepPin HIGH  
    WAIT 2000 microseconds  
    SET stepPin LOW  
    WAIT 2000 microseconds  
  END FOR  
  
  WAIT 2000 milliseconds  
END FUNCTION
```

Complete Code for ESP32

```
//Importing Libraries
#include "HX711.h"
#include <LiquidCrystal_I2C.h>

// Defining pin connections & motor's steps per revolution
int relayPin = 26;
int revrelayPin = 27;
int servoredPin = 18;
int servobluePin = 19;
const int dirPin = 17;
const int stepPin = 23;
const int stepsPerRevolution = 900;
const int LOADCELL_DOUT_PIN = 2;
const int LOADCELL_SCK_PIN = 4;

// Setting the LCD address & size
LiquidCrystal_I2C lcd(0x27, 16, 2);

HX711 load_cell;
HX711 scale;

float weight = 0.0;
float oldweight = 0.0;
float newweight = 0.0;

void setup() {

    // Initializing the serial communication
    Serial.begin(115200);

    // Initialize the LCD
    lcd.init();
    lcd.clear();
    lcd.backlight();

    //Display Weight
```

```

lcdprint(weight);

// Setting the pins as OUTPUT
pinMode(relayPin, OUTPUT);
pinMode(revrelayPin, OUTPUT);
pinMode(servobluePin, OUTPUT);
pinMode(servoredPin, OUTPUT);
pinMode(stepPin, OUTPUT);
pinMode(dirPin, OUTPUT);

// Initialize the relay to be off (LOW turns off the relay)
digitalWrite(relayPin, LOW);
digitalWrite(revrelayPin, LOW);

//Initializing valve position
closeValve(servoredPin);
closeValve(servobluePin);

//Starting the load cell
scale.begin(LOADCELL_DOUT_PIN, LOADCELL_SCK_PIN);
scale.set_scale(3257.28);
scale.tare();

//running the main code
five_looper();

//end
delay(1000);
lcd.setCursor(0, 0);
lcd.clear();
lcd.print("    Task");
lcd.setCursor(0, 1);
lcd.print("    Completed");
}

void loop(){

}

void five_looper() {

```



```
for (int i = 0; i < 5; i++) {  
    //moving spout forward  
    movespout(true);  
  
    //red servo open  
    openValve(servoredPin);  
  
    //pump for 4 sec  
    pump(4000);  
  
    //weight  
    weight = scale.get_units(10);  
  
    //Display Weight  
    lcdprint(weight);  
  
    //Precise Measurement  
    precisepump(oldweight, 5.0);  
  
    // put the ADC in sleep mode  
    scale.power_down();  
    delay(1000);  
    scale.power_up();  
  
    oldweight = weight;  
  
    //removing remaining water  
    reversepump(4000);  
  
    //red servo close  
    closeValve(servoredPin);  
  
    //moving spout back  
    movespout(false);  
  
    //blue servo open  
    openValve(servobluePin);  
  
    //pump for 5.5 sec  
    pump(5500);  
}
```

```

//weight
weight = scale.get_units(10);

//Display Weight
lcdprint(weight);

//Precise Measurement
precisepump(oldweight, 10.0);

// put the ADC in sleep mode
scale.power_down();
delay(1000);
scale.power_up();

oldweight = weight;

//removing remaining water
reversepump(3500);

//blueservo close
closeValve(servobluePin);
}
}

void moveServo(int pulseWidth, int servoPin) {
    // Manually generate the PWM signal for the servo
    digitalWrite(servoPin, HIGH);
    delayMicroseconds(pulseWidth);
    digitalWrite(servoPin, LOW);

    delay(20 - (pulseWidth / 1000)); // 20ms period minus the pulse width in milliseconds
}

void closeValve(int pin) {
    if (pin == servoredPin) {
        Serial.println("Closing Red valve");
    } else {
        Serial.println("Closing Blue valve");
    }
}

```

```

// Sweep from 0 to 90 degrees
for (int angle = 0; angle <= 90; angle++) {
    int pulseWidth = map(angle, 0, 180, 500, 2500); // Mapping angle to pulse width (500µs to 2500µs)
    moveServo(pulseWidth, pin); // Moving servo to current angle
    delay(15);
}
}

void openValve(int pin) {
    if (pin == servoredPin) {
        Serial.println("Opening Red valve");
    } else {
        Serial.println("Opening Blue valve");
    }
}

// Sweep back from 90 to 0 degrees
for (int angle = 90; angle >= 0; angle--) {
    int pulseWidth = map(angle, 0, 180, 500, 2500); // Mapping angle to pulse width
    moveServo(pulseWidth, pin); // Moving servo to current angle
    delay(15);
}
}

void pump(int dur) {
    // Turn the relay ON
    Serial.println("Pump ON");
    digitalWrite(relayPin, HIGH); // Activating the relay
    delay(dur);

    // Turn the relay OFF
    Serial.println("Pump OFF");
    digitalWrite(relayPin, LOW); // Deactivating the relay
    delay(2000);
}

void reversepump(int dur) {
    // Turn the relay ON
    Serial.println("Reverse Pump ON");
    digitalWrite(revrelayPin, HIGH); // Activating the relay
    delay(dur);
}

```

```

// Turn the relay OFF
Serial.println("Reverse Pump OFF");
digitalWrite(revrelayPin, LOW); // Deactivating the relay
delay(2000);
}

void precisepump(float oldweight, float target) {
  for (int i = 0; i < 10; i++) {
    weight = scale.get_units(10);
    newweight = weight - oldweight;

    //Display weight
    lcdprint(weight);

    if (newweight < target) {
      //pump for 0.8 seconds
      pump(800);
    } else {
      Serial.println("Target Weight dispensed");
      lcd.clear();
      lcd.setCursor(0, 0);
      lcd.print("Fluid Released: ");
      lcd.setCursor(0, 1);
      lcd.print(newweight / 10.0, 1);
      delay(1000);
      break;
    }
    //Display weight
    lcdprint(weight);
  }
}

void lcdprint(float weight) {

  //Printing on serial monitor
  Serial.print("Weight: ");
  Serial.println(weight, 1);

  // Display text
  lcd.setCursor(0, 0);

```

```
lcd.print("Weight: ");  
lcd.setCursor(0, 1);  
lcd.print(weight, 1);  
}  
  
void movespout(bool forw) {  
  if (forw) {  
    // Set motor direction clockwise  
    digitalWrite(dirPin, HIGH);  
    Serial.println("Moving Spout Forward");  
  } else {  
    // set motor direction anticlockwise  
    digitalWrite(dirPin, LOW);  
    Serial.println("Moving Spout Backward");  
  }  
  
  // Spin motor slowly  
  for (int x = 0; x < stepsPerRevolution; x++) {  
    digitalWrite(stepPin, HIGH);  
    delayMicroseconds(2000);  
    digitalWrite(stepPin, LOW);  
    delayMicroseconds(2000);  
  }  
  
  delay(2000);  
}
```

Team Id: TW-LAM-630